



<b>Systems</b>	<b>1</b>
<b>Examples of use</b>	<b>2</b>
<b>Set-up time savings</b>	<b>3</b>
<b>SPEEDY fast closing clamp</b>	<b>4</b>
<b>Mounting brackets for SPEEDY</b>	<b>5</b>
<b>SPEEDY assembly modules</b>	<b>6</b>
<b>SPEEDY <i>Compact</i> 1000</b>	<b>7</b>
<b>SPEEDY plate sets</b>	<b>8</b>
<b>SPEEDY assembly cylinders</b>	<b>9</b>
<b>Flow-power</b>	<b>10</b>
<b>Control valve and shut-off valve</b>	<b>11</b>
<b>Retractable nipples</b>	<b>12</b>
<b>Pressure booster and devices</b>	<b>13</b>
<b>Pallets perforated</b>	<b>14</b>
<b>Plates perforated</b>	<b>15</b>
<b>Clamping devices - mechanical</b>	<b>16</b>
<b>Attachments</b>	<b>17</b>
<b>Handling equipment</b>	<b>18</b>
<b>Order number index</b>	<b>19</b>
<b>Examples for application</b>	<b>20</b>

For mounting data sheets see [www.stark-inc.com](http://www.stark-inc.com)



<b>Systems</b> .....	<b>5</b>	Shut-off valve for installation in fast closing clamp-plates .....	47
<b>Examples of use</b> .....	<b>6</b>	Control valve with ball valve to piping $\varnothing$ 6/4 .....	47
Amortization through reduced set-up time .....	7	<b>Retractable nipples</b> .....	<b>48</b>
<b>Advantages of the system at a glance</b> .....	<b>9</b>	Retractable nipple with zero point for SPEEDY 1000 .....	49
<b>Technical Data</b> .....	<b>10</b>	Retractable nipple with equalizer for SPEEDY 1000 .....	49
<b>SPEEDY fast closing clamp</b> .....	<b>12</b>	Retractable nipple without centering for SPEEDY 1000 .....	49
SPEEDY <i>Record</i> 1000 round .....	12	Retractable nipple for SPEEDY 1000 with flange .....	50
SPEEDY <i>Record</i> 1000 square .....	12	Zero point flange .....	50
SPEEDY <i>Record</i> 1000 set .....	13	Equalizing flange for SPEEDY 1000 .....	51
SPEEDY <i>Record</i> 1000 blow out round .....	14	Retraction flange for SPEEDY 1000 .....	51
SPEEDY <i>Record</i> 1000 blow out square .....	14	Retractable nipple with zero point for SPEEDY 2000, 3000 .....	52
SPEEDY 1000 round .....	16	Retractable nipple with equalizer for SPEEDY 2000, 3000 .....	52
SPEEDY 1000 square .....	16	Retractable nipple without centering for SPEEDY 2000, 3000 .....	53
SPEEDY 1000 set .....	17	Mounting examples .....	53
SPEEDY 2000 round .....	18	Retractable nipple with zero point for SPEEDY <i>Sweeper</i> 2000 .....	54
SPEEDY 2000 square .....	18	Nipple fastening for variant D .....	55
SPEEDY 2000 set .....	19	Nipple fastening for variant E .....	55
SPEEDY 3000 round .....	20	<b>Pressure booster with/without "third hand" function (DHF)</b> .....	<b>56</b>
SPEEDY 3000 square .....	20	<b>Pressure booster and devices</b> .....	<b>58</b>
SPEEDY <i>Gigant</i> 1000, 2000, 3000 round .....	21	Pressure booster and devices .....	58
SPEEDY <i>Gigant</i> 1000, 2000, 3000 square .....	21	Pumping set, electric .....	59
<b>Mounting brackets for SPEEDY</b> .....	<b>22</b>	<b>Pallets perforated</b> .....	<b>60</b>
Mounting brackets for the fast closing clamps .....	22	Accuracy (standard) .....	60
Some possible combinations of mounting brackets .....	22	Variations in perforated pallets and plates .....	61
Mounting bracket form 1 .....	23	Pallet perforated .....	62
Mounting bracket form 2 .....	23	Pallet perforated- square .....	63
Mounting bracket form 3 .....	23	Pallet perforated- round .....	63
Mounting bracket form 4 .....	23	<b>Plates perforated</b> .....	<b>64</b>
Mounting bracket for clamping on perforated grid .....	23	Plate perforated- square .....	65
Practical examples .....	24	Plate perforated- round .....	65
<b>SPEEDY assembly modules</b> .....	<b>25</b>	<b>Clamping devices - mechanical</b> .....	<b>66</b>
SPEEDY <i>Tornado</i> 1000 assembly module with raised supports and blow out ducts .....	25	Zero point reference also on down draw clamps .....	66
SPEEDY <i>Tornado</i> 2000 assembly module with raised supports and blow out ducts .....	25	Guidelines for working with clamping devices .....	67
SPEEDY <i>Tornado</i> 3000 assembly module with raised supports and blow out ducts .....	26	Down draw clamp for pegging out zero point .....	68
Practical example .....	26	Down draw clamp for pegging out zero point, narrow edition .....	68
<b>SPEEDY Compact 1000</b> .....	<b>27</b>	Adjustable down draw clamp .....	69
SPEEDY <i>Compact</i> 1000 assembly .....	27	Down draw clamp for pegging out - zero point reference - raised model .....	70
SPEEDY <i>Compact</i> 1000 assembly with blow out ducts and mount control .....	28	Down draw clamp - adjustable - raised model .....	70
<b>SPEEDY plate sets</b> .....	<b>29</b>	Simple prism clamp, as cover with zero point .....	71
SPEEDY 1000 plate set, 4-fold .....	29	Stop rotatable by 360°, with zero point, straight version .....	72
SPEEDY 1000 plate set, 6-fold .....	29	Stop rotatable by 360°, with zero point, corner version .....	72
SPEEDY 1000 plate set, 8-fold .....	29	Base for flat clamps, deep drawing clamps etc. .....	73
<b>SPEEDY assembly cylinders</b> .....	<b>30</b>	Flat clamp single, for setting out with zero point .....	74
SPEEDY assembly 1000, 2000, 3000 round .....	30	Flat clamp single, for setting out .....	74
SPEEDY assembly 1000, 2000, 3000 square .....	30	<b>Attachments</b> .....	<b>76</b>
Examples of use .....	31	Retractable nipple key for SPEEDY 1000 .....	76
SPEEDY <i>Tornado</i> 1000, 2000, 3000 round assembly module with raised supports and blow out ducts .....	32	Torque wrench .....	76
SPEEDY <i>Tornado</i> 1000, 2000, 3000 square assembly module with raised supports and blow out ducts .....	32	SPEEDY sealing plug for fast closing clamps 1000, 2000, 3000 .....	77
SPEEDY <i>Tornado</i> 1000, 2000, 3000 round assembly module with raised supports, blow out ducts and drainage of coolant .....	33	Protection during transport of retractible nipples in the pallet .....	77
SPEEDY <i>Tornado</i> Einbau 1000, 2000, 3000 square assembly module with raised supports, blow out ducts and drainage of coolant .....	33	Lock stopper for perforation variations C / D / E .....	78
SPEEDY <i>Twister</i> 1000, 2000 round assembly module with raised supports and blow out ducts .....	34	Sliding block with pin (to position in the T-groove) .....	78
Sample application: SPEEDY <i>Twister</i> 1000, 2000 .....	34	Washers for clamping devices .....	78
SPEEDY assembly cylinders in use .....	36	Precision collar bolt .....	79
SPEEDY <i>Sweeper</i> 2000 .....	38	Connection block complete .....	79
<b>SPEEDY Sweeper assembly modules</b> .....	<b>40</b>	Coupling .....	80
SPEEDY <i>Sweeper</i> - multiple coupling .....	40	Hydraulic hose with couplings on both sides .....	80
<b>SPEEDY with Flow-Power</b> .....	<b>41</b>	Connecting parts together with screw-on nipple .....	80
<b>Flow-Power</b> .....	<b>42</b>	Positioning nipple .....	81
Flow-Power NW4 SPEEDY-side .....	43	Straight screw connection .....	82
Flow-Power NW4 pallet-side .....	43	90° screw connection .....	82
SPEEDY 1000, 2000 round with up to 4 Flow-Power ducts NW4 .....	44	T-screw connection .....	82
<b>Development and quality assurance</b> .....	<b>45</b>	Cross connection .....	82
<b>Control valve</b> .....	<b>46</b>	Adjustable 90° .....	82
Mechanical locking control valves .....	46	Adjustable-T .....	82
<b>Shut-off valve</b> .....	<b>47</b>	Swivel screw connector .....	83
		T-Swivel screw connector .....	83
		Brass pipe for SPEEDY assembly (for a freely selectable bore hole gauge) .....	83
		Service - set (the set of seals includes all O-rings and sealing rings) .....	83
		<b>Handling equipment</b> .....	<b>84</b>
		<b>Order number index</b> .....	<b>86</b>
		<b>Examples for application</b> .....	<b>88</b>
		<b>General terms of delivery</b> .....	<b>90</b>